

# BLAST EXEC



## OPERATOR INSTRUCTIONS



### EXTRA HIGH BACK BLAST EXEC CHAIR

With height adjustable arms

#### DIMENSIONS (mm)

Seat Width	480
Seat Height	470 - 610
Seat Depth	460
Overall Width	570



### MEDIUM BACK BLAST EXEC VISITOR CHAIR

Chrome cantilever with fixed arms

#### DIMENSIONS (mm)

Seat Width	480
Seat Height	470 - 610
Seat Depth	460
Overall Width	570



### OPTIONAL FEATURES

The following are optional extras to the range.



Polished Base



Silver Base